



Cranberry Boom Installation Guide

Preparation

- Ensure the bog is fully flooded.
- Pull the booms off the pallet and lay them out near the bog.
- Connect each section by sliding the aluminum end connectors together and securing them with the toggle pins.

Deploying the Boom

- Two workers usually carry the boom to opposite sides of the bog.
- Place the boom in the water along the bog's edge.

Encircling the Berries

- Workers slowly pull the boom around the bog, sweeping berries inward.
- Some farms use boats or small harvest machines to help move the boom.

Herding to the Collection Point

- The boom is gradually tightened into a circle or directed toward a corner of the bog.
- The corralled berries are concentrated at the pump or conveyor area.

Securing & Collecting

- Once berries are gathered, secure the boom so they stay contained.
- Pump, convey, or vacuum the berries out for transport.