



*Environmental*

**PH#: 941-747-4151**

**4455 18<sup>th</sup> St. East, Bradenton, FL 34203**

**barriers@aerflo.com**

## **HazMat 95-Gallon Spill Kit - Absorbs up to 79.7 Gallons**

### **SPKHZ-95 Specifications**

<b>Dimensions:</b>	ext. dia. 31.75" x 41.5" H
<b>Shipping</b>	31.75" W x 41.5" L x 31.75" H
<b>Dimensions:</b>	
<b>Sold as:</b>	1 per package
<b>Absorbency:</b>	Up to 79.7 gal. per package
<b>Weight:</b>	105.4 lbs.
<b># per Pallet:</b>	2
<b>Incinerable:</b>	No
<b>Ship Class:</b>	175
<b>Includes:</b>	150 - 15" x 19" Yellow HazMat HeavyWeight SonicBonded Pads (YPB100H) 12 - 3" x 4' Yellow HazMat Sorbent Socks (YSO430) 6 - 3" x 8' Yellow HazMat Sorbent Socks (YSO815) 7 - 18" x 18" Yellow HazMat Sorbent Pillows (YPIL1818) 3 - 1 lb. Plug & Dike Epoxy Putty (A-PND) 2 - Pair Nitrile Gloves (A-GLV-NIT) 1 - Safety Goggles (A-GOG) 4 - 30" x 6" x 60" Yellow Disposal Bags & Ties (A-DISP BAG) 1 - Emergency Response GuideBook (A- EGB) 1 - 3" x 5" Vinyl Spill Kit Label (A- KITLABEL) 1 - 31.75" x 41.5" Yellow 95-Gallon OverPack (1H2/X295/S) (A95OVER) 6 - 6" X 2" TamperProof Seals (A-SEAL)



### **Metric Equivalent Specifications**

<b>Dimensions:</b>	ext. dia. 81cm x 105cm H
<b>Shipping</b>	81cm W x 105cm L x 81cm H
<b>Dimensions:</b>	
<b>Absorbency:</b>	Up to 301.7 L per package
<b>Weight:</b>	47.8 kg

### **Regulations and Compliance:**

49 CFR 173.3(c)(1) - If a container of hazardous waste is damaged or leaking, it can be placed in a compatible salvage drum that meets UN criteria for shipping

40 CFR 263.31 - Transporters, "must clean up any hazardous waste discharge that occurs during transportation...so that the hazardous waste discharge no longer presents a hazard to human health or the environment."

40 CFR 263.30(a) - In the event of a spill, transporters must, "take appropriate immediate action to protect human health and the environment."

33 CFR 154.1047(c)(2) - Concerning navigation and navigable waters, a facility which handles, stores or transports Group V petroleum oils must identify response plan resources such as containment booms and other methods.

29 CFR 1910.1450(e) - OSHA requires containment and cleanup materials for spills in laboratories to reduce occupational exposure to hazardous chemicals.

29 CFR 1910.120(j)(1) - Under an OSHA requirement, "DOT-specified salvage drums or containers and suitable quantities of proper absorbents shall be kept available and used in areas where spills, leaks, or ruptures may occur."